



593

Gravity Feed Dissolver with Solenoid

THANK YOU FOR YOUR INTEREST IN OUR PRODUCTS

Please use this equipment carefully and observe all warnings and cautions.

*****NOTE*****

WEAR	protective clothing and eyewear when dispensing chemicals or other materials or when working in the vicinity of all chemicals, filling or emptying equipment or changing metering tips..
ALWAYS	observe safety and handling instructions of the chemical manufacturers. direct discharge away from you or other persons or into approved containers. dispense cleaners and chemicals in accordance with manufacturer's instructions. Exercise CAUTION when maintaining your equipment. re-assemble equipment according to instruction procedures. Be sure all components are firmly screwed or latched into position.
KEEP	equipment clean to maintain proper operation.

Installation and Operation:

1. Drill holes for the four wall anchors with a (9/32") drill, using the mounting board as a template. Make sure the board is level.
2. Connect the vacuum breaker; the elbow fitting attaches to the metal tube extending from the bowl and the straight fitting connects to the tubing from the solenoid.
3. Connect water supply line, 3/8" OD tube, to the inlet of unit.
4. Connect outlet as required.
5. Place chemical bottle securely in solid bowl assembly.
6. Connect solenoid using included AC adapter.
7. Adjust pressure regulator per chemical manufacturer recommendations.

